

---

Please do not tamper with the cabling in this room, nor move the TV unit away from the wall. If you require assistance please ask at the SIZ desk.

---

## DISPLAY

The TV screen is best operated with the LG remote control handset which should be present. In the absence of the remote control, the TV can also be operated by pressing the corresponding word\symbol on the bottom right edge of the TV.

### Please switch off the system after use

To switch off the TV screen, either use the LG remote control and press the Power button, or on the TV itself press the symbol on the bottom right edge.

Shutdown the PC if used.

---

## PC

There is a standard network computer and its display is shown on the large TV screen. A wireless mouse and keyboard has been provided.

If the picture does not appear on the TV, then on the remote press **INPUT**, and then use the ▲ ▼ ◀ ▶ buttons to select **RGB** – then press the **OK** button.

---

## HDMI for LAPTOPS & OTHER DEVICES

An HDMI cable should be connected to the HDMI socket on the left side of the TV, which is the HDMI-3 input. The cable is labelled HDMI-3 – connect it to your device.




HDMI

On the remote or TV press **INPUT**, and then use the ▲ ▼ ◀ ▶ buttons to select **HDMI-3** – then press the **OK** button.

For devices lacking HDMI, you will need an HDMI adaptor. The SIZ in the LRC carries a very limited stock of adaptors for standard devices and these adaptors can be loaned on your University ID card.

---

## VOLUME



The sound level on the TV can be raised lowered by using the volume up\down button on the remote or pressing the + - buttons on the TV. Remember that *Windows* has its own volume bottom-right of screen and websites like YouTube have a volume control below the clip.

---

For assistance contact the SIZ desk.

Please report any non-urgent issues to the SIZ via Support Me > Self Service Portal on the Intranet.