University of Chichester

Mordington 1.15 - User Guide





CLEVERTOUCH DISPLAY

The Clevertouch display screen is interactive to touch. To switch on the display use the Crestron push-button panel to the left of the display.

Switch on the display screen by pressing the **POWER ON** button on the Crestron push-button panel. A red light next to this button indicates the power is On.

Switch off the display screen by pressing the **POWER OFF** button on the Crestron push-button panel. A red light next to this button indicates the power is Off.

PC

A micro PC is currently located behind the display and must be switched on manually.



The PC shows a constant blue light when On, but a flashing blue light when power-saving – if it is power saving, push the PC's flashing power button once to wake it up.

Press the **PC** button on the Crestron push-button panel to display the PC on the screen. The selected choice is indicated by a red light.



LAPTOPS

The connection plate includes HDMI connections. Use an appropriate cable for your device and connect to socket marked **HDMI 1**.

Press the **LAPTOP 1** button on the push-button panel.

If the laptop image does not appear on the screen you may need to instruct your device to output its image. In *Windows*, press the *Windows* Logo key and P key at the same time, then choose Duplicate.

For Apple Mac go to Display Properties and choose to Mirror display.

VOLUME

It is recommended to raise the volume on the PC within *Windows* – or on your laptop etc – before raising the volume on the display.

Use the **VOL** ▲ and **VOL** ▼ buttons to adjust the display volume.

The volume can be muted by pressing the **MUTE** button. When MUTE is selected its red light will flash.

University of Chichester

Mordington 1.15 - User Guide





DVD

This room does not contain a DVD player, but if needed a DVD player be loaned from the SIZ and connected to one of the HDMI sockets on the connection plate.

If connecting a DVD player to **HDMI 2** socket then press the **LAPTOP 2** button on the push-button panel to select the HDMI input.

CAMERA & LECTURE RECORDING

There is no fixed camera in this Seminar room. Lectures can still be recorded by using an appropriate webcam.

For information on lecture recording contact the Skills Team.



skills@chi.ac.uk

TRAINING

To learn how to make the best use of the facilities in any of the lecture rooms please make an appointment with a member of the Skills Team.

This can be requested in Self-Service by clicking **Support Me**, then **My IT Training** and selecting "PC/MAC/AV/Assistive Technology Training Request".

For emergency help where there is a fault with the lecture system phone the SIZ on (01243 81) 6222

For non-emergency enquiries please use the Support Me button in the Self-Service on the intranet.