




DISPLAY

The display screen is operated with the Crestron push-button panel below the display screen.

Switch on the display screen by pressing the **POWER ON** button on the Crestron push-button panel. A red light next to this button indicates the power is On.

Switch off the display screen by pressing the **POWER OFF** button on the Crestron push-button panel. A red light next to this button indicates the power is Off.



PC

A micro PC is housed inside the display's metal stand and must be switched on manually. An access slot is located on the right-hand side of the metal stand.

Press the **PC** button on the Crestron push-button panel to display the PC on the screen. The selected choice is indicated by a red light.

USB devices can be connected using the socket on the connection panel or to the front of the PC via the access slot.

LAPTOPS

The connection plate includes an HDMI connection for connection of a laptop or other HDMI device.



Press the **HDMI** button on the push-button panel to display the connected device.

Devices which lack an HDMI must use an adapter.

DVDs and CDs

Currently, this room does not contain a DVD player.



The connection plate on the lectern includes an HDMI connection & power socket which a DVD player can be connected to for the purpose of playing DVDs or CDs.

Press the **HDMI** button on the push-button panel to select the HDMI input.

CAMERA & LECTURE RECORDING

There is no fixed camera in the Will Hunter room.

Lectures can still be recorded by using an appropriate webcam.

Also, the adjacent Elizabeth Swan Room contains a fixed camera on the ceiling for the purpose of lecture recording. Using the camera controls the camera may be rotated towards the Will Hunter room. You must be logged into the PC in Elizabeth Swan and running the *Panopto* software to see the camera feed.

For information on lecture recording contact the **Skills Team**.

VOLUME

It is recommended to raise the volume on the PC within *Windows* – or on your laptop etc – before raising the volume on the display.

Use the **VOL ▲** and **VOL ▼** buttons to adjust the display volume.

The volume can be muted by pressing the **MUTE** button. When MUTE is selected its red light will be lit.

TROUBLESHOOTING

- Push-button panel unresponsive / showing no red lights – the Crestron panel is powered by its network connection. Ensure network cable 501 is connected to network socket 146.
The unit will take a 30 seconds or so initialise when plugged in.
 - PC gives network connection error – ensure network cable 502 is connected to network socket 145.
-

**For emergency help where there is a fault with the lecture system phone the SIZ on
(01243 81) 6222**

For issues with musical equipment please ask at the Music reception desk.

For non-emergency enquiries please use the Support Me button in the Self-Service on the intranet.
