

## DISPLAY



The screen is also height adjustable

This is a large format touch screen which responds to either your hands or to pens that should be located at each edge of the screen.

## POWER

Normally just touching the screen will bring it out of standby. Otherwise use the power button located at the far right hand side of the front of the screen. This can be used to switch the screen off when you have finished your session



If the screen is powered on, and you still do not see anything displayed, please check to ensure that the PC housed in the lower rear of the unit is switched on

If the computer is on already on – or showing the message “unable to detect your input signal”, move the mouse or press any key on the wireless keyboard.



## SWITCHING BETWEEN PC AND OTHER DEVICES

To switch between the *Windows* PC and other device sources either press the **MENU** button found below the screen’s Power button (see above), or alternatively swipe upwards from the bottom of the screen to reveal the **General Setting** window.



Choose a source by tapping on it. The blue dots below a source show which are currently active (i.e. available and connected). There are also volume and screen brightness controls available on the General Setting screen.

## Camera and Microphones:

There is a good quality web camera situated above the display screen.

Please note this is not a ‘streaming’ room, and the camera is facing outwards – and therefore will only pick up the wider room, (in case of a remote participant). The Microphones are quite effective for tutorials, but may be limited for group work, large groups, or for the participants furthest away. A Bluetooth ‘Jabra’ conference microphone, and a camera / tripod for more flexible situations may be available from SIZ loans.

### LAPTOPS

For best results, please use the PC within the Mobile display. If you must connect a laptop, please use an appropriate cable, normally HDMI (1), and connect your laptop to one of the vacant sockets on the right-hand side of the display. For example, connect to the socket marked HDMI 1 and then select HDMI 1 on the General Setting window to display the connected device.

### PEN & INTERACTIVITY



The screen is responsive to touch with a hand/finger and will register up to 20 points of contact on the screen simultaneously if you would like multiple drawers/writers to use the screen at once. There is also a special pen which can be used upon the screen. The pen is usually located on the side edge of the display.

To draw on the screen press the inward pointing arrow at the side of the screen, then choose the pen icon. You can then draw with your fingers and erase with your hand.

Drawings made on the screen can be saved but are saved to the *Android* system so you will need a USB storage device to transfer them to. See *ANDROID* section below.



The Home icon will jump to the *Android* system home screen. If you are using the *Windows* PC then do not press this icon unless you intend to go to *Android*.



The pen icon is used to choose a drawing pen or highlighter pen, and to select the colour of the chosen pen.



Zoom tools for: increase zoom, decrease zoom and return to full screen



The scissor icon is a screenshot button which takes a screenshot of the screen and saves it to a folder on the *Android* system of the display device. To retrieve the file you must use the *Android* system where it can be copied to a USB device.

### ANDROID



The Clevertouch display also contains an *Android* operating system. You can switch to the *Android* system by touching one of the Home buttons found in the on-screen menus.

The functionality of the *Android* system is too complex to be summarised here.



To learn more about how to use the *Android* side of the Clevertouch display, visit their help site (choosing Plus Series) at: <https://gettingstarted.clevertouch.com>

### TRAINING

To learn how to deliver the best learning experience using the facilities in any of the lecture rooms please contact the Skills Team. [skills@chi.ac.uk](mailto:skills@chi.ac.uk)



This can also be requested in the Self-Service area of the intranet by clicking **Support Me**, then **My IT Training** selecting "**Audio Visual Equipment Training Request**".

**For emergency help where there is a fault with the lecture system phone the SIZ on (01243 81) 6222**

For non-emergency enquiries please use the **Support Me** button in the **Self-Service** area on the intranet and select: My Teaching > IT Support (Teaching Room/Open Access)